

Installation for Paver Light™ in Concrete

1. Pre-wire light fixtures with connections inside the base fixture
2. Allow slack in between lights to allow for movement of concrete when pouring
3. Wire can be placed in plastic conduit or use a drop line covered in sand.
4. Light fixture to be set at finished elevation with stoned aggregate under fixture for drainage purposes.
5. Make sure the lens and the base are together, cover the lens with masking tape before concrete is poured to keep the lens clean